

Water maintenance

Commercial chlorine water maintenance



For videos and best
setup experience,
install the Plunge app



Commercial chlorine water maintenance

To keep your Plunge water safe and clean in a commercial environment, see below for the protocol we recommend. This is a protocol using 15% chlorine and 85% non-chlorine shock. If your water gets murky, you can try clarifier and you can always drain and refill. If your plunge ever stops filtering or is off, be sure to empty the plunge, the filter, and the chiller. Sitting water will not be sanitary for the system. If your flow appears slower than normal even with a new filter, you'll need to clean out the pump. High water flow is essential for good filtration.

Key

Tbsp = tablespoon
Tsp = teaspoon

First steps

The Plunge

1. Fill your Plunge with fresh water using the carbon hose filter.
2. Add **3 Tbsp** of Sirona Spa Up (Formerly Alkalinity Up)
3. Add **1 Tbsp** of Sirona Replenish (Chlorine)*
4. Add **1 Tbsp** of Sirona Clarifier

The Plunge XL/ Plunge All-In

1. Fill your Plunge with fresh water using the carbon hose filter.
2. Add **4 Tbsp** of Sirona Spa Up (Formerly Alkalinity Up)
3. Add **4 Tsp** of Sirona Replenish (Chlorine)*
4. Add **4 Tsp** of Sirona Clarifier

* Dissolve Sirona Replenish (Chlorine) in hot water before putting into Plunge.

Key

Tbsp = tablespoon
Tsp = teaspoon

The Plunge

Chlorine reading	Add	PH reading	Add	Alkalinity reading	Add
0-1 PPM	1 Tbsp Sirona Replenish (Chlorine)	7.1 or below	2 Tsp Sirona Spa Up (Formerly Alkalinity up)	0-20	3 Tbsp Sirona Spa Up (Formerly Alkalinity up)
2 PPM	1 Tsp Sirona Replenish (Chlorine)	7.2 - 7.3	1 Tsp Sirona Spa Up (Formerly Alkalinity up)	21-40	2 Tbsp Sirona Spa Up (Formerly Alkalinity up)
3+ PPM	Leave as is	7.4 - 7.9	Leave as is	41-60	1 Tbsp Sirona Spa Up (Formerly Alkalinity up)
		8 or above	Use Spa Down	61-80	1 Tsp Sirona Spa Up (Formerly Alkalinity up)
				81-120	Leave as is
				180 or above	Use Spa Down

The Plunge XL/ Plunge All-In

Chlorine reading	Add	PH reading	Add	Alkalinity reading	Add
0-1 PPM	4 Tsp Sirona Replenish (Chlorine)	7.1 or below	3 Tsp Sirona Spa Up (Formerly Alkalinity up)	0-20	4 Tbsp Sirona Spa Up (Formerly Alkalinity up)
2 PPM	2 Tsp Sirona Replenish (Chlorine)	7.2 - 7.3	2 Tsp Sirona Spa Up (Formerly Alkalinity up)	21-40	3 Tbsp Sirona Spa Up (Formerly Alkalinity up)
3+ PPM	Leave as is	7.4 - 7.9	Leave as is	41-60	2 Tbsp Sirona Spa Up (Formerly Alkalinity up)
		8 or above	Use Spa Down	61-80	2 Tsp Sirona Spa Up (Formerly Alkalinity up)
				81-120	Leave as is
				180 or above	Use Spa Down

Remember: Dissolve Replenish (Chlorine) in hot water before putting into Plunge

Weekly or 2x/ week with high use

Drain and refill your Plunge

1. Connect a hose to the drain on the back of the Plunge.
2. Open the valve.
3. Follow **'First Steps'** above.



Play Video