

remove fence posts and panels as needed to make excavation and regrading and provide for access for equipment

Spread excavation spoils along bench and down slope outside fence line existing fence to remain at existing elevation

Grade drops on this edge - provide formwork as necessary to form spa shell, provide landscaping rocks or blocks at exposed shell for finish

and surround skimmer, color and finish to match existing

and the second

