

Attachment details for the sign at 1125 Lincoln Avenue:

For an install, tapcon concrete screws that are 3" long and epoxy in the holes will be used to attach the sign. See attachment. We will use 6-8 screws, 3-4 across the top and bottom with one being in each corner.

For the lettering, the letters will have VHB tape on the back which is a premium exterior tape, and we will add epoxy to the back as well. We will hang them according to the pattern the manufacturer sends and apply the letters one at a time, peeling the backer off the tape, applying a tad of epoxy or silicone, put the letter in the pattern and press firmly for 45-60 seconds.